Self-Calibration

Group1

Special thanks to

이석호 박사님 박규은 박사님 Lee, Kibeop Park, Sunghyun Jo, Yun-A Bang, Taehyeon


Why do we need calibrations?

Phase errors:


- Emission is smeared and astrometry is degraded.
- Flux is reduced and weak emission undetected
- Anti-sysmmetric artefacts in image

Amplitude errors:


- Spotty or stripy emission
- Flux reduced and/or Noise increased
- Symmetric artefacts in image




Our Target - TW Hya



Atmospheric difference of position and time between Phase-calibrator and targets (< a few degrees and times)





postulate the cleaned result as an analog of the phase calibrator at the source position!

Sanity Check


inspection of sufficient S/N ratio must be preceded

e.g., S/N >20 for ~25 antennas


- strong outlier included in the model
- severe variability of the data
- over-calibrated image

significant residuals still exist after phase calibration (with J1037-265)


after cleaning the TW_Hya data



Self-calibration process



Self-calibration process



clean image
(*calibrated.image)

clean image

Self calibration round 1 (phase calibration)

clean image

Self calibration round 2 (phase calibration)

clean image

Self calibration round 3 (phase calibration)

clean image

Self calibration round 4 (phase + amplitude calibration)


Adjusting parameter


[Adjusting weighting]


- case 1(briggs)
- case 2(uniform)
- case 3(natural)





- what is solint
- solint result

























































Comparison of three cases





gaincal

gaincal(vis, caltable=", field=", spw=", intent=", selectdata=True, timerange=", uvrange=", antenna=", scan=", observation=", msselect=", solint='inf', combine=", preavg=-1.0, refant=", refantmode='flex', minblperant=4, minsnr=3.0, solnorm=False, normtype='mean', gaintype='G', smodel=", calmode='ap', solmode=", rmsthresh=", corrdepflags=False, append=False, splinetime=3600.0, npointaver=3, phasewrap=180.0, docallib=False, callib=", gaintable=", gainfield=", interp=", spwmap=", parang=False) [source]

vis, caltable, field, spw, intent, selectdata, solint, combine, preavg, refant, refantmode, minblperant antenna, minsnr, solnorm, gaintype ...


gaincal

```
gaincal(vis, caltable=", field=", spw=", intent=", selectdata=True, timerange=", uvrange=", antenna=", scan=", observation=", msselect=",
solint='inf', combine=" preavg=-1.0, refant=", refantmode='flex', minblperant=4, minsnr=3.0, solnorm=False, normtype='mean', gaintype='G',
smodel=", calmode='ap', solmode=", rmsthresh=", corrdepflags=False, append=False, splinetime=3600.0, npointaver=3, phasewrap=180.0,
docallib=False, callib=", gaintable=", gainfield=", interp=", spwmap=", parang=False) [source]
```

vis, caltable, field, spw, intent, selectdata, solint, combine, preavg, refant, refantmode, minblperant antenna, minsnr, solnorm, gaintype ...

On-source

solint defines how frequently gain solutions (phase or amplitude) are calculated in time.combine controls which axes of the data are grouped together when calculating solutions.



solint defines how frequently gain solutions (phase or amplitude) are calculated in time.

combine controls which axes of the data are grouped together when calculating solutions.

Solution Interval Trade-off

- Short solint → Enables precise tracking of temporal variations but reduces SNR, potentially leading to unstable solutions
- Long solint → Improves SNR but may fail to capture temporal variations accurately

Goal!

To understand how self-calibration performance depends on solution time interval


Strategy

obs = 5 scan


Combine	Solint	Combine	Solint	Combine	Solint
-	int (6.05s)	-	34.8s (0.1 scan)	-	87s (¼ scan)
-	116s (⅓ scan)	-	174s (½ scan)	-	inf (1 scan)
scan	509s (⅓ obs)	scan	763.5s (½ obs)	scan	inf (1 obs)

3 Phase self-cal + 1 Amplitude self-cal = 4 * 9 = **36 test sets**


Method



3rd Phase calibration image




3rd Phase calibration image



3σ clean image results

Result



Result P = Phase self-cal / A = Amplitude self-cal


Flagging limit (<15%) → Failed solution P: 87s (¼ scan); A: 116s (⅓ scan)

Optimal solint

P: 1st → ½ obs; 2nd, 3rd → ½ scan
Iteration increase → More refined solutions at finer solint.
A: ½ obs, More accurate solutions at longer solint
∴ Require higher SNR data

Solint='inf' + combine='scan'?

SNR degradation in self-cal solutions significantly varying between scans?



Thank You

clean image	1st image	2nd image	3rd image	4th image	final image
peak intensity (mJy/beam)	314	335	367	387	396
rms (mJy/beam)	5.64	2.83	2.51	2.46	2.49
SNR	56	118	146	157	159
flux (Jy)	1.57	1.73	1.88	1.90	1.88
beam size (arcsec)	0.560 * 0.416	0.559 * 0.415	0.580 * 0.439	0.600 * 0.445	0.614 * 0.457

clean image	1st image	2nd image	3rd image	4th image	final image
peak intensity (mJy/beam)	298	319	320	321	310
rms (mJy/beam)	3.88	2.36	2.33	2.31	2.26
SNR	77	135	137	139	137
flux (Jy)	1.86	2.00	2.01	2.03	1.83
beam size (arcsec)	0.537*0.390	0.537*0.390	0.537*0.390	0.537*0.390	0.537*0.390

clean image	1st image	2nd image	3rd image	4th image	final image
peak intensity (mJy/beam)	377	397	456	497	528
rms (mJy/beam)	10.3	4.72	3.56	3.33	2.97
SNR	36.6	84	128	149	278
flux (Jy)	1.69	1.8	1.95	1.96	1.97
beam size (arcsec)	0.609 * 0.470	0.608 * 0.470	0.654 * 0.519	0.705 * 0.539	0.730 * 0.565